



English

1. Mount the four arms to the disc.
2. Mount the projector to the arms. Use the supplied spacers, bolts and washers.
3. Make sure the top plate is in the right position and mount the plate to the ceiling.
4. Mount the projector to the top plate by tightening the ball joint. Turn ball clamping ring to set the resistance of the adjustment.
5. Extra fixation of the ball joint can be obtained by using a screwdriver through the hole of the ball clamping ring and turning it tight. This same hole can be used for placing an optional anti-theft lock.

Nederlands

1. Monteer de vier armpjes aan de bracketschijf.
2. Monteer de projector aan de armpjes. Gebruik hiervoor de meegeleverde afstandbussen, bouten en sluitringen.
3. Bepaal de juiste positie van de plafondplaat en monteer deze aan het plafond.
4. De projector kan vervolgens worden opgehangen door het kogelgewricht aan te draaien.
5. Indien nodig kan er extra fixatie van de kogel worden verkregen door een schroevendraaier door het gat van de kogelklemring te steken en deze te gebruiken om de ring aan te draaien. Nadat de projector is gefixeerd kan door hetzelfde gat een hangslot worden gedaan.