



Parts list:

- 13: Screws
- 14: Screws
- 15: Washers
- 16: Washers
- 17: Bracket
- 18: Vertical post
- 19: Vertical post

Exploded view showing the base assembly with parts 1 through 19. Screws 11 (M4) and 12 (M5) are indicated.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
1	2	1	2	4	1	1	1	1	1	1	1	2	2	2	4	7	1	1

Step 1: Attaching the base plate (1) and legs (5) to the main assembly.

Step 2: Attaching the side panels (6) and additional legs (5) to the base.

Step 3: Inserting the vertical posts (4) into the base.

Step 4: Attaching the vertical post (18) to the base.

Step 5: Attaching the shelves (2) to the vertical posts.

Step 6: Attaching the top panel (8) to the vertical post (12) using screws (13).

Step 7: Attaching the top panel (3) to the vertical post (19) using screws (13).

Step 8: Attaching the top panel (3) to the vertical post (17) using screws (13).

Step 9: Mounting the TV onto the top panel.